



Leaving an Expansion Joint: Shiplap

100°F



50°F



Below 50°F

